



AC Hardline Block-off Panel Installation Instructions

Tools required:

- Socket set with extensions
- Basic hand tools

Installation:

1. After removing as many AC components as desired (AC compressor, condenser, dryer and hardlines), use the factory nut to block off the AC hard lines. This plate will seal the hardlines from dirt and debris.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.