

Heater Core Delete and Block-off Panel Installation Instructions

Tools required:

- Socket set with extensions
- Basic hand tools
- Power Drill and 7/32" Drill Bit
- *Optional: Foam weather-strip tape*

Installation:

1. With the dashboard and heater core removed, use the plates as a guide as shown. Inside the car, center the plates to the hole, mark and drill out the center holes first, as shown in **IMAGE 1 and 2**. *Space the firewall heat shield from the motor side of the firewall with small blocks of wood and ensure that you do not drill into anything other than the firewall.*
2. Use the flanged hardware and fasten the plate to the firewall
3. Continuing to use the plates as a guide, mark and drill the remaining holes **ensuring that the plate forms to the firewall**
4. Use the remaining four (4) washer plates, to cover the central mounting holes in the firewall as shown in **IMAGE 3**
5. Fasten all bolts until they are snug.

NOTE: You can use weatherstripping foam tape under the block off plates to create a water tight seal



IMAGE 1



IMAGE 2



IMAGE 3

WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.