



F-BODY BATTERY MOUNT INSTRUCTIONS

PART# BR001

Required Tools:

- 3/8" ratchet with 9/16" and 3/8" socket
- 9/16" wrench
- 1/2" wrench
- Drill with 1/8" and 3/8" drill bit

Installation:

1. Remove the passenger side rear plastic cover using a coin to turn the plastic screws.
2. Remove the jack and spare tire from the wheel well.
3. Position the BMR Battery mount in the wheel well in such a way that the battery mounting tabs rest on the frame rail. Mark the holes for drilling.
4. Drill a 1/8" starter hole at each upper mark. Reposition the battery mount and insert the self-tapping bolts into the holes. Tighten.
5. Locate the other two mounting holes down in the well. Using the holes in the battery mount as a guide, drill two 3/8" holes through the well.
6. Insert the supplied bolts, washers and lock nuts. Tighten.



WWW.BMRFABRICATION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during the installation of this product.