



CAMARO/G8 REAR SWAY BAR END LINK INSTALLATION

ELK006 – 2008-2009 PONTIAC G8, 2010-2011 Camaro

RECOMMENDED TOOLS:

5mm Allen wrench

Wrenches: 15mm, 11/16", 3/4"

INSTALLATION:

1. Lift the vehicle and safely support it under the frame rails.
2. Using a 15mm wrench and a 5mm Allen wrench, remove the nuts from the OE sway bar end links. One is located on the control arm and one at the sway bar. The 5mm Allen wrench is used to prevent the center of the OE end link from turning while loosening the nut with the 15mm wrench. Remove the OE end links.
3. Adjust the end link to the approximate length of the OE end link. Rotate the ends to simulate the OE design then tighten the jam nuts using an 11/16" and 3/4" wrench. The lower tie rod on the end link attaches to the inside of the control arm mount (side facing the differential) and the upper tie rod attaches to the outside of the sway bar.
4. Once installed, tighten both bolts to 25 ft/lbs.
5. Lower vehicle.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.