



POLISHED RADIATOR COVER

Part # RS001

Tools required:

10mm wrench

3/16" allen wrench

Installation:

1. Using a 10mm wrench, remove the three bolts holding the factory shroud in place and remove the shroud.
2. Remove the rubber radiator isolators from the existing shroud and place into the BMR shroud.
3. Install the BMR shroud using the provided stainless hardware and spacers. Spacers go underneath the outside boltholes.



WWW.BMRFABRICATION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.

