



## STEERING RACK MOUNTING BUSHING

**BK008**

**NOTE: This bushing will not fit vehicles equipped with electric steering.**

### REQUIRED TOOLS:

- Hydraulic jack and 2 stands (lift optional)
- 15mm socket
- Pry-bar

### INSTALLATION:

1. Lift vehicle and support with stands under the rocker jack points or K-member.
2. Remove passenger side front wheel.
3. The most accessible position to access the bushing is through the passenger side wheel well. Using a 15mm socket, remove the (2) rack mounting bolts on the passenger side.
4. Pry the saddle off the OE bushing.
5. Lift up on the rack and remove the OE mounting bushing. *NOTE: Loosening the driver's side mounting bolts makes this step much easier but is not necessary.*
6. Install the BMR polyurethane mounting bushing into position and re-install the OE saddle.
7. Re-install the OE mounting bolts and torque to 45 ft/lbs.
8. Install wheel and lower vehicle.

**WWW.BMRSUSPENSION.COM**

*This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any caused to the vehicle/person during installation or use of this product.*