



G-BODY DRIVESHAFT LOOP INSTALLATION

Part # DSL003

Tools Required:

Jack	Jack Stands
13mm wrench	11mm wrench

Installation:

1. Lift the vehicle and support with jack stands under the frame rails.
2. Using the 11mm wrench, remove the driveshaft and tape the cups onto the u-joint to avoid needle bearing loss.
3. Using the 13mm wrench, remove the OE chassis brace that is located just behind the transmission tail-shaft.
4. Place the driveshaft loop into position where the OE brace was bolted with the loop facing upwards. Insert the bolts and tighten.
5. Reinstall the driveshaft and tighten the u-joint bolts.
6. Lower vehicle.



WWW.BMRFABRICATION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.