



DRIVESHAFT TUNNEL BRACE

Part # DTB001

Required Tools:

- Ratchet and 13mm socket
- Jack and jack stands

Installation:

1. Raise the rear of the vehicle and place stands under the frame rails.
2. Remove all 4 bolts that attach the factory brace and remove the brace.
3. Install the BMR tunnel brace and torque bolts to 24 ft/lbs.
4. Lower vehicle.



WWW.BMRFABRICATION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.