



HCS760 – Crotch Strap Bar for 2015-2022 S550 Mustang

REQUIRED TOOLS:

- T50 Torx Bit Socket

Crotch Strap INSTALLATION:

- 1) Unfasten the front two (2) screws of the driver seat with a T50 torx socket.
- 2) Depending on clearance for your seat brackets, you can flip the bar either way as shown below.
- 3) The bar can also be mounted in between the seat bracket and chassis depending on your setup.
- 4) Torque the two screws back to 45ftlbs.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicle's manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.