



SB111 INSTALLATION INSTRUCTIONS

Tools required:

- Grease
- 15mm & 21mm Socket

Instructions:

1. With the vehicle Parking Brake engaged and Transmission in Drive/Gear, use a floor jack to raise the front of the vehicle and securely rest vehicle on jack stands.
2. Loosen and remove factory Sway Bar Saddles with a 15mm socket shown in **Image 1**.
3. Loosen and remove lower Sway Bar Links with a 21mm socket shown in **Image 2**.



4. Apply grease the new bushing, as shown in **Image 3**. The more grease the better, excess will be extruded when the new sway bar saddles are tightened and can be wiped away.
5. Torque the sway bar end link nuts to 96ftlbs and the sway bar saddle bolts to 44ftlbs.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.