



STB017 INSTALLATION INSTRUCTIONS 2011-PRESENT CAMARO

REQUIRED TOOLS:

1. 3/8" drive ratchet with 13mm socket
2. Torque wrench (optional)

INSTALLATION:

1. Open hood and locate the mounting holes shown in **IMAGE 1**.
2. Position the BMR Strut Tower Brace over these holes and insert the supplied 8mm bolts and washers.
3. Verify that brace is centered then tighten bolts to 25 ft/lbs.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to vehicle/person during installation or use of this product.