



## TRAILING ARMS

TCA027 – 2008-PRESENT PONTIAC G8, 2010 CAMARO

### Tools required:

- 3/8" drive ratchet
- 18mm socket
- 18mm wrench

### Installation:

1. Lift the vehicle until the wheels are off the ground. Support with jack stands. **NOTE:** Installation is much simpler with wheels/tires removed however it is not necessary to remove them.
2. Start with the outer bolt. Hold the nut with the wrench and loosen the bolt using the socket.
3. Using the socket, remove the front trailing arm bolt. **NOTE:** the nut is welded to the subframe and is not necessary to hold with a wrench.
4. Remove both bolts and remove the trailing arm. **NOTE:** outer bolt can only be removed if the suspension is in the full droop position.
5. Install the BMR trailing arm back into the original position and insert the bolts.
6. Repeat steps 2-5 on the other side.
7. Torque bolts to 80 ft/lbs.
8. Lower vehicle.



*This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any caused to the vehicle/person during installation or use of this product.*