



## UTCA012 - UPPER CONTROL ARM INSTALLATION

*Upper control arms, DOM, polyurethane bushings*

### Installation:

1. Lift vehicle and support with jack stands under the frame rails.
3. Remove all 4 bolts from the control arms and remove both control arms.
4. Install the new upper control arms and leave the bolts finger tight until all 4 bolts are installed.
5. Support the car by the rear end to properly load the polyurethane bushings and tighten all bolts.
6. Torque all four bolts to 80 ft./lbs.
7. Using a grease gun with a silicone based polyurethane lube, lube each grease fitting with 1-2 pumps. For maximum longevity, re-grease at 500 miles and then every other oil change.
8. Lower vehicle.



[WWW.BMRSUSPENSION.COM](http://WWW.BMRSUSPENSION.COM)

*This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.*